

# INSTALLATION INSTRUCTIONS PT-A-904

## Prisoner Transport Sound Deadening Insulation

### TOOLS REQUIRED:

Tape measure      Safety goggles      Razor knife      Straight edge

### PARTS SUPPLIED:

1      54"inch wide x 30" long Insulation / Sound Deadening Material      PT-A-904

### INSTALLATION INSTRUCTIONS:

1. Carefully measure walls from floor to ceiling and between ribs. Measure ceiling side to side between the ribs.
2. Cut material to size with razor knife. It is best to cut material on top of cardboard with black Mylar side up.
3. Carefully peel PSA backing paper off of the material.  
We recommend only peeling a little of the paper at the top, stick to desired starting point and peel paper as you work down the wall.
4. Stick to walls and ceiling. We recommend two people for applying material. The adhesive is very sticky and can be difficult to handle for one person. Lightly push material against the wall in a few spots, but **DO NOT** completely push on all areas until you are sure the position is correct. Peel back off and reposition if necessary.  
Firmly push all material against wall or ceiling when all positioning is correct.

### Notes:

1. We recommend measuring and cutting all pieces before sticking anything to the walls.
2. Medium height long vans will use all the material. Be careful to layout properly or you will not have enough to completely cover the ceiling.
3. First apply insulation between the ribs on walls.
4. Apply insulation between the ribs on ceiling starting at the rear.
5. Apply / cover ribs and wheel wells only if you have extra material.  
Low height regular length vans will have plenty of material.



Installation with ribs and rear AC area not covered



Installation with most areas covered using spare material.