



LINE	QTY.	PART NUMBER	DESCRIPTION
1	1	11298	BRACKET, MOUNT, 45° 3.5" LOWER OFFSET BASE W/SLOTS
2	2	11441	SPACER, 1"
3	4	16123	WASHER, 5/16" FLAT, SAE ZP BLK
4	2	16126	WASHER 1/2 FLAT ZP
5	4	16143	WASHER, 5/16" LOCK, ZP BLK
6	4	16335	SCREW, 5/16-18 X 3/4"
7	2	16523	HRDW.SCRW,MS,HEX,HEX,17MM,10.9,ZN,BLK,M10X1.25X60
8	1	38237	ASSEMBLY, WELDMENT, HDM BASE, TOYOTA TACOMA 2022+

INSTALLATION INSTRUCTIONS

1. REMOVE PASSENGER SIDE FRONT SEAT BOLTS.
2. PLACE SPACERS AND BASE OVER SEAT BRACKETS.
3. INSTALL SUPPLIED LONGER SEAT BOLTS AND WASHERS AND TIGHTEN TO VEHICLE MANUFACTURER'S TORQUE SPECIFICATION.
4. ATTACH LOWER OFFSET TO BASEPLATE WITH 5/16" BOLTS, LOCK WASHERS AND FLAT WASHERS ANGLE TOWARDS CENTER OF VEHICLE.
5. FOLLOW GENERAL INSTRUCTIONS FOR POLE AND UPPER MOUNT PARTS.

HAVIS HAVIS, INC.		75 JACKSONVILLE RD. WARMINSTER, PA. 18974 1-800-524-9900	
TITLE: TOYOTA TACOMA HDM BASE			
DO NOT SCALE DRAWING			
SIZE A	DWG. NO. C-HDM-1021-INST	REV 2-23	
WEIGHT (LB): 8.759	SCALE: 1:8	SHEET 1 OF 1	