



TOOL LIST:

1. #2 PHILLIPS SCREW OR DRILL DRIVER

ASSEMBLY STEPS:

1. CONNECT **PAX A35** TO **BACKPLATE** AND SECURE USING **M5 X 8MM LONG SCREWS**.
2. ATTACH THE **PAX A35** TO THE **TAILWIND FLEXIPOLE PLUS STAND** BY SNAPPING IT INTO PLACE AS SHOWN.
3. ROUTE THE **DEVICE CABLE** AS DESIRED.

DWG. NO. CST00195	REV. C	TITLE
DRAWN T. STRAND	DATE 10/18/2021	BACKPLATE FOR PAX A35

SHEET 1 OF 1	
--------------	--



REVISIONS				
REV	DESCRIPTION	DATE	BY	CHK'D
C		02/11/22	AN	AN

CUSTOMER INSTRUCTIONS