


INSTALLATION INSTRUCTIONS:

- 1. DETERMINE THE BEST MOUNTING LOCATION FOR YOUR APPLICATION.
- 2. USE THE UPPER STIFFENER PLATE AS A DRILL GUIDE AND DRILL (4X) 9/32 HOLES THROUGH THE MOUNTING SURFACE. MOUNTING SURFACE TO BE BETWEEN .06" AND .60" THK.
- 3. PLACE LOWER STIFFENER PLATE UNDER MOUNTING SURFACE, USING SUPPLIED HARDWARE; SECURE LOWER AND UPPER STIFFENER AND TORQUE PROPERLY INTO INDUSTRY STANDARD.
- 4. MOUNT THE OPTIONAL DEVICE (i.e. C-MD-102) TO THE COWL MOUNT BEFORE MOUNTING IT IN PLACE.
- 5. PLACE THE COWL MOUNT OVER THE UPPER STIFFENER PLATE AND SECURE IN PLACE USING SUPPLIED HARDWARES.
- 6. TIGHTEN ALL FASTENERS TO THE APPROPRIATE INDUSTRY STANDARD.




ITEM NO.	QTY.	PART NUMBER	DESCRIPTION
1	8	GSM31005	WASHER, 1/4 FLAT ZP, BLACK
2	8	GSM31026	WASHER 1/4 LOCK ZP BLK
3	4	GSM33003	SCREW 1/4-20 X 1 1/4 HHCS ZP
4	4	GSM33124	SCREW 1/4-20 X 3/4 PPHMS

DRAWING NUMBER:  
C-HDM-135-INST

WARNING: ALL HAVIS INC. PRODUCTS ARE DESIGNED WITH SAFETY OF USE AND INSTALLATION IN MIND. HOWEVER, IT IS THE SOLE RESPONSIBILITY OF THE OWNER/OPERATOR OF A VEHICLE USING HAVIS INC. MOUNTING AND DOCKING EQUIPMENT, TO INSURE THAT THE EQUIPMENT IS INSTALLED SO THAT IT WILL NOT INTERFERE WITH VEHICLE OPERATION, INTERFERE WITH SAFETY DEVICES, OBSTRUCT VIEW OF DRIVING CONDITIONS, OR IN ANY WAY DEGRADE OCCUPANT SAFETY. IMPROPER INSTALLATION CAN CAUSE SERIOUS INJURY IN THE EVENT OF AN ACCIDENT. INSTALLATION SHOULD ONLY BE PERFORMED BY QUALIFIED PROFESSIONALS. COMPUTERS AND MOTION DEVICES MUST BE MOVED TO AND STOWED/SECURED IN THEIR SAFE DRIVING POSITIONS BEFORE OPERATING VEHICLE.

PRODUCT DESCRIPTION

COWL MOUNT TALL IS 1.75" TALL AND MOUNTS TO A FLAT SURFACE, ALLOWS USE OF HAVIS MOTION ACCESSORIES.

PRODUCT I.D. <b>C-HDM-135</b>	DATE <b>10-20-10</b>
PRODUCT NAME <b>COWL MOUNT TALL</b>	
 1-800-524-9900 WWW.HAVIS.COM	WEIGHT: (LBS) <b>2.69</b>
	REV. DATE <b>01-18</b>