

HOLE PATTERN FOR MOUNTING HAVIS ARMREST:  
CM93042-1 OR CM93051

NOTE: ARMPAD HAS MULTIPLE POSITIONING OPTIONS.

HOLE PATTERN FOR MOUNTING ON TOP OF A TILT SWIVEL  
DEVICE: C-MD-201, C-MD-202, C-MD-203, C-MD-204, C-MD-  
101, C-MD-102, C-MD-103, C-MD-105, C-MD-107, C-MD-109,  
C-HDM-301, C-HDM-302, C-HDM-303, C-HDM-304, C-HDM-305

CABLE PASS THRU LOCATIONS

ZIP TIE LOCATION

HOLE PATTERN FOR MOUNTING ON TOP OF HAVIS  
ARMREST ASSEMBLY: C-ARM-103, C-ARM-104, C-ARM-105.

NOTE: ARMPAD MUST BE REMOVED FROM ARMREST  
ASSEMBLY FIRST.

#### HARDWARE KIT CONTENTS:

LINE NO.	QTY.	ITEM NO.	DESCRIPTION
1	1	GSM19997	7/8" GROMMET
2	1	CM86430	HRDW, PLUG, 7/8", BLK,
3	4	GSM33000	SCREW 1/4-20 X 1/2 HHCS, BLK, ZP, GRD 5
5	4	GSM30023	NUT 1/4-20 HEX FLANGE SERRATED ZP, BLK
6	2	HW-ZT-0004	ZIP TIE, .09" W x .03" T x 4" L, 18# TENSILE

**WARNING:** ALL HAVIS INC. PRODUCTS ARE DESIGNED WITH SAFETY OF USE AND INSTALLATION IN MIND. HOWEVER, IT IS THE SOLE RESPONSIBILITY OF THE OWNER/OPERATOR OF A VEHICLE USING HAVIS INC. MOUNTING AND DOCKING EQUIPMENT, TO INSURE THAT THE EQUIPMENT IS INSTALLED SO THAT IT WILL NOT INTERFERE WITH VEHICLE OPERATION, INTERFERE WITH SAFETY DEVICES, OBSTRUCT VIEW OF DRIVING CONDITIONS, OR IN ANY WAY DEGRADE OCCUPANT SAFETY. IMPROPER INSTALLATION CAN CAUSE SERIOUS INJURY IN THE EVENT OF AN ACCIDENT. INSTALLATION SHOULD ONLY BE PERFORMED BY QUALIFIED PROFESSIONALS. COMPUTERS AND MOTION DEVICES MUST BE MOVED TO AND STOWED/SECURED IN THEIR SAFE DRIVING POSITIONS BEFORE OPERATING VEHICLE.

DRAWING NO.

**C-PM-1001-INST**

PRODUCT DESCRIPTION

**PRINTER MOUNT, PENTAX  
POCKETJET**

**HAVIS**

1-800-524-9900  
WWW.HAVIS.COM

WEIGHT: (LBS)

**1.49**

REV. DATE

**09-14-20**