





MD-501-K Rugged Mounting System

INSTALLATION MANUAL




Get Started

- | | |
|--------------------------------|------------------------------------|
| A Mount assembly | F Phillips M4 flat head (4) |
| B Clamp block | G 1/4" flat washer (4) |
| C Clamp bolt 5-1/2" (4) | H 1/4-20 locknut (4) |
| D Clamp bolt 4-1/2" (4) | I VESA plate |
| E Clamp bolt 3-1/2" (4) | J Nut plate |



Installation

- *Note*** Adapts to columns of any shape, 1" - 4" (25.4 - 101.6mm)
Note Clamp mounts in horizontal or vertical orientation




- 1 Select clamp bolt (C,D,E) - insert into slots on mount (4x)
- 2 Position clamp (B) against column and into clamp bolts
- 3 Push clamp bolts snug against column
- 4 Assemble washers (G) (4x)
- 5 Thread locknuts (H) (4x) using a 7/16" wrench - torque no more than 30 in. lbs

MD-501-K-INST REV A


Adjustments

Note Adjustments apply to both clamp and head



- 1 To rotate arm/head - squeeze buttons on both sides
- 2 Rotate arm to position - release buttons - confirm lock
- 3 To position arm/head - loosen adjustment knobs
- 4 Move arm/head into position
- 5 Tighten adjustment knobs


Attachments - VESA mount



- 1 Insert nut plate (J) around collar on head assembly
- 2 Place VESA plate (I) (or other device/bracket/etc)
- 3 Tighten M4 Phillips screws (F) (4x) into nut plate

Attachments - direct mount

Note Hex head screws with washers are suggested for the easiest installation



- 1 Thread two screws (not provided) into device
- 2 Hang the device onto mount head
- 3 Thread other two screws through mount head and into the device as shown