



INSTALLATION INSTRUCTIONS


SEE SHEET 2 FOR WALL MOUNT

DETAIL A



COUNTER MOUNT

SEE SHEET 2 FOR WALL MOUNT



TOOL LIST:

- #2 PHILLIPS SCREW OR DRILL DRIVER
- 3/32" DRILL BIT
- OPTIONAL** 1 1/2" (1.50") SPADE BIT

ASSEMBLY STEPS:

- USING **SWIVEL BASE** AS A TEMPLATE, MARK AND DRILL 3X 3/32 HOLES FOR USE WITH **3X #12 X 1.00 PHILLIPS WOOD SCREWS**.
- (OPTIONAL) DRILL A 1 1/2" (1.50") THROUGH HOLE INTO YOUR **COUNTER** FOR CABLE TO PASS THROUGH.
- ATTACH **SWIVEL BASE** TO **COUNTER** USING **3X #12 X 1.00 PHILLIPS WOOD SCREWS** AS SHOWN IN **DETAIL A**.
- ASSEMBLE THE **UPPER 2X M4 X 10MM LONG PHILLIPS SCREWS** INTO TOP HOLES OF **MONITOR** LEAVING 1/8" OF SPACE BETWEEN THE BACK OF THE **MONITOR** AND THE SCREW HEAD.
- PLACE THE **MONITOR** ONTO **MONITOR BRACKET** USING THE **VESA 100MM SLOT** OR **VESA 75MM KEYHOLE** PATTERN FOR BOTH SIDES. SEE: **DETAIL B**
- INSTALL THE **LOWER 2X M4 X 10MM LONG PHILLIPS SCREWS** AND TIGHTEN THE **UPPER 2X M4 X 10MM LONG PHILLIPS SCREWS**.
- ATTACH THE **MONITOR CABLE** TO **BRIDGE LANCE** WITH **CABLE TIE** AS SHOWN IN **DETAIL C**. CONTINUE ROUTING THE **MONITOR CABLE** THROUGH THE **SWIVEL BASE** AS SHOWN.
- ATTACH THE **SWIVEL BASE COVERS** TO THE **SWIVEL BASE** AS SHOWN IN **DETAIL A**.

THE INFORMATION CONTAINED IN THIS DRAWING IS THE SOLE PROPERTY OF HAVIS AND REPRODUCTION IN PART OR IN WHOLE WITHOUT THE WRITTEN PERMISSION OF HAVIS IS PROHIBITED.


REV.	DESCRIPTION	DATE	SY	CHK'D
A		02/14/22	SY	
1				

DIMS. AND TOLERANCES PER ASME Y14.5 - 1994 UNLESS OTHERWISE SPECIFIED DIMENSIONS ARE IN INCHES TOLERANCES ARE:		DRAWN S. YANG		
FRACTIONAL ± 1/32		DATE 2/14/2022		
2 PLC. DEC. ± .03		CHECKED		
3 PLC. DEC. ± .010		DATE		
ANGULAR ± 0°30'		DO NOT SCALE DRAWING		TITLE
		MATERIAL -		DISPLAY MOUNT, SINGLE VESA, STANDARD DUTY
		FINISH -		SIZE
				C
				DWG. NO.
				DM-10-101
				REV. A
				SHEET 1 OF 2

INSTALLATION INSTRUCTIONS

SEE SHEET 1 FOR COUNTER MOUNT

DETAIL A



WALL MOUNT

SEE SHEET 1 FOR COUNTER MOUNT

TOOL LIST:

- #2 PHILLIPS SCREW OR DRILL DRIVER
- 3/32" DRILL BIT
- OPTIONAL** 1 1/2" (1.50") SPADE BIT

ASSEMBLY STEPS:

- USING **SWIVEL BASE** AS A TEMPLATE, MARK AND DRILL 3X 3/32 HOLES FOR USE WITH **3X #12 X 1.00 PHILLIPS WOOD SCREWS**.
- (OPTIONAL) DRILL A 1 1/2" (1.50") THROUGH HOLE INTO YOUR **WALL / VERTICAL SURFACE**. FOR CABLE TO PASS THROUGH.
- ATTACH **SWIVEL BASE** TO **WALL / VERTICAL SURFACE** USING **3X #12 X 1.00 PHILLIPS WOOD SCREWS** AS SHOWN IN **DETAIL A**. ENSURE CORRECT ORIENTATION BEFORE INSTALLING.

NOTE: CONTINUE INSTALLATION WITH STEP 4 ON SHEET 1.

THE INFORMATION CONTAINED IN THIS DRAWING IS THE SOLE PROPERTY OF HAVIS AND REPRODUCTION IN PART OR IN WHOLE WITHOUT THE WRITTEN PERMISSION OF HAVIS IS PROHIBITED.

REV.	DESCRIPTION	DATE	BY	CHK'D		
	DRAWN S. YANG					
	DATE 2/14/2022					
	CHECKED					
	DATE					
	DO NOT SCALE DRAWING					
	MATERIAL					
	FINISH					
DIMS. AND TOLERANCES PER ASME Y14.5 - 1994 UNLESS OTHERWISE SPECIFIED DIMENSIONS ARE IN INCHES TOLERANCES ARE:						
FRACTIONAL	± 1/32				TITLE	DISPLAY MOUNT, SINGLE VESA, STANDARD DUTY
2 PLC. DEC.	± .03				SIZE	C
3 PLC. DEC.	± .010				DWG. NO.	DM-10-101
ANGULAR	± 0°30'	REV.	A	SHEET 2 OF 2		